

Fire Stopping

Ductwork

Installing services without fire walls constructed first can lead to problems fire stopping penetrations at a later date.

Large apertures for ductwork within ceiling voids makes access difficult and possibly unsafe to seal above.

Fire walls should ideally be constructed prior to any first fix services being installed. Services penetrations can then be site marked and holes cut out to size as necessary.

Holes for ductwork are cut out of the fire wall ready for the fire dampers to be installed.

